





Infill Panels for Open Frame Leg

Reference Number: 6TP00307

HARDWARE LIST

<p>(A)</p>  <p>6TP40444 BRKT,INFILL\ OUT</p>	<p>(B)</p>  <p>6TP40770 BRKT,INFILL\ IN</p>	<p>(C)</p>  <p>5112200 SCR,SM PNR 10x1/2 T-A ZN</p>	<p>(D)</p>  <p>5418010 BUMPER</p>
---	--	--	--

Tools Needed

Measuring Tape
Phillips Square Driver

Pre-assembly of infills

1. Identify which is the inside and outside fillers.
The outside filler is always the taller of the two.
2. On inside filler, attach mounting bracket (B) using fastener (C). (Fig. 1A)
3. On outside filler, attach mounting bracket (A) also using fastener (C). (Fig. 1B)
4. On the bottom corners of the infills, apply bumpers (D) 4 places approximately 2" from the edge. (Fig 1A & 1B).

Final assembly of infills onto the open framed leg

1. Position the outside infill. Holding the outside infill in place, install the inside infill interlocking the brackets. (Fig 2A & 2B)

