

















# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

HARDWARE LIST			
 <p>6AJ4343 BUMPER, DOOR STOP, Qty-10</p>	 <p>7321440 SCR, SM PNP 4 X 5/8, Qty-20</p>	 <p>6TP42216 Minifix Push In Dowel, Qty-15</p>	 <p>6TP42217 Minifix 15 CAM Zinc, Qty-15</p>
 <p>6AJ4330 OUTRIGGER CASTER WELDMENT, OUTSIDE, Qty-2</p>	 <p>6AJ4326 DOOR CASTER WELDMENT, OUTSIDE, Qty-2</p>		 <p>6AJ4324 DOOR CASTER BRACKET, INSIDE, Qty-2</p>
 <p>6AJ4307 4\" CASTER,BOLT,BLACK,RED WHEEL, Qty-2</p>	 <p>6AJ4338 THIN HEX NUT, 7/16\"-14 THREAD x 1/4\" HT. Qty-2</p>		 <p>6AJ4344 SCR. MACH FLH HEXDR, #10-32 X .500 Qty-8</p>
 <p>6AJ4327 OUTRIGGER CASTER BRACKET, INSIDE, Qty-2</p>	 <p>6AJ4308 4\" CASTER,RECT,BLACK,RED WHEEL, Qty-2</p>		
 <p>6AB4084 SCREWS, Qty-8</p>	 <p>4AH4003 NUT,HEX LOCK 5/16-18, Qty-8</p>	 <p>6AB4134 SCR, MACH, BUH, 1/4-20 X 5/8, Qty-10</p>	 <p>6AJ4309 4\" CASTER, APEX, BLACK, RED WHEEL, Qty-1</p>

# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485


Fig 1

## STEPS:


### 1. Assembly of Cabinet

- 1.1 Install 7x 6TP42217 Locking Cams into Septum Panel.  
(Fig. 1)

Note: Ensure the arrow on the cams align with the opening for the push-in connectors.



- 1.2 Install 2x 6TP42216 Push-In Connectors and 4x 6TP42217 Locking Cams into Top Panel.  
(Fig. 2)



- 1.3 Install 2x 6TP42216 Push-In Connectors, and 4x 6TP42217 Locking Cams into Bottom Panel.  
(Fig. 3)




Fig 3

# Backdrop Mobile Markerboard Wall



Reference Number: UBBD442485

Fig 4

## 1. Assembly of Cabinet (cont.)

- 1.4 Attach Septum to Top and Bottom Panels.  
(Fig. 4)

Note: The septum and top and bottom panels will only align in the correct orientation.



# Backdrop Mobile Markerboard Wall


Reference Number: UBBD442485

Fig 5

## 1. Assembly of Cabinet (cont.)

- 1.5 Install 6TP42216 Push-In Connectors Into Front Panel and Attach Front Panel.  
(Fig. 5)

Note: It is recommended to elevate the unit off the ground at minimum 12" by placing the front panel face down on sawhorses, a table, or blocks. This will make installing the outriggers casters in steps 1.8 easier to manage.



# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

## Tools Needed

Phillips Drive

Predrilling Ø3mm Hole and Phillips Drive  
(only for additional shelves)

## 1. Assembly of Cabinet (cont.)

- 1.6 Attach 2x Shelves with 4x 7487140 Screws each.  
(Fig. 6)






Fig 7

- 1.7 Attach Additional Shelves with  
4x 7487140 Screws each.  
(Fig. 7)

Note: Additional shelves do not have set locations and are determined individually. See dealer representative for specific heights. Requires predrilling a Ø3mm x 3mm deep hole.



# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

## Tools Needed



5/32" Hex Drive

1/2" Socket

## 1. Assembly of Cabinet (cont.)

- 1.8 Attach 6AJ4309 Apex Caster with  
4x 6AB4134 Screws.  
(Fig. 8)



Fig 8



- 1.9 Loosely Sub-Assemble LH/RH  
Outrigger Casters 4AH4003, 6AJ4308,  
6AJ4327, 6AJ4330.  
(Fig. 9)

Note: Loose fitting this assembly first makes  
installing the whole piece to the unit simpler.

Fig 9



# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

## Tools Needed


5/32" Hex Drive and Phillips Drive

Fig 10

## 1. Assembly of Cabinet (cont.)

- 1.10. Attach LH/RH Outrigger Caster Assemblies with 3x 6AB4134 Screws and 4x 6AB4084 Screws each. (Fig. 10)

Note: After the three casters are tightened to the unit it can be lifted upright by two people.



Completed Cabinet

# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

## 2. Assembly of LH/RH Door Panels

Note: Loosening the hinge plates on the doors and front panel will make aligning the hinges easier. Ensure the hinge plates are tightened after installing the door.

Fig 11






Fig 12

- 2.1 Sub-Assemble 2x Door Casters  
6AJ4307, 6AJ4326, 6AJ4338.  
(Fig. 12)

Note: The door casters have an inside and outside direction, ensure the visible hardware is installed on the hinge side of the doors.





# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

## 2. Assembly of LH/RH Door Panels (cont.)

- 2.2 Attach Casters to Door Panels with 6AJ4324 Plate and 4x 6AJ4344 Screws per Door. (Fig. 6 and 7)


Note: Magnetic Catch Preinstalled by the factory, ensure they are fastened properly

Fig 6

### Tools Needed


1/8" Hex Drive

11/16" Opened ended wrench and/or socket wrench



Note: The door caster installation requires a threaded rod and nut to be attached to the caster assembly. The 11/16" nut can be tightened with an opened ended wrench or carefully dissamble the caster and use a socket wrench.

Fig 7



# Backdrop Mobile Markerboard Wall


Reference Number: UBBD442485

## 3. Hang Doors onto Cabinet


(Fig. 8 and 9)

Note: Loosening the hinge plates will make aligning all hinges easier.

Tighten after slotting in all hinges. **Fig 8**



**Fig 9**



# Backdrop Mobile Markerboard Wall

Reference Number: UBBD442485

## Tools Needed

Phillips Drive

### 3. Hang Doors onto Cabinet (cont.)

- 3.1 Attach 10x 6AJ4343 Door Bumpers with  
2x 7321440 Screws each.  
(Fig. 10 and 11)

Fig 10




Fig 11

