

Campagna Wall Wallcovering Installation Instructions

KnollTextiles

Do not discard. Please read before hanging wallcovering.

Installation Instructions

For best results, KnollTextiles recommends that a qualified wallcovering installer is employed.

Terms and Conditions

- Materials must be examined prior to installation.
- Please check that all rolls are the correct color, pattern or direction.
- No claims will be allowed for hanging the wrong color or pattern.
- No adjustments will be allowed after the material is cut.
- Material should be tested by hanging NO MORE THAN 3 STRIPS. If you have any questions after hanging the first 3 strips, call Customer Service at 866-565-5858. KnollTextiles will not be responsible for any labor costs thereafter.

Wall Preparation

- All previous wallcovering and paint residue should be removed, and surface protrusions and lowspots sanded and filled so that hanging surface is clean, smooth, and thoroughly dry.
- KnollTextiles does not recommend installing wallcovering over existing material.
- Glossy surfaces should be sanded to dull the surface, and dust removed with a dry cloth.
- Surface should be thoroughly sealed; a quality wallcovering primer should be used on all surfaces.
- Lining the walls is usually not needed. The installer should determine if necessary.
- If a paper or canvas liner is thought necessary, the same heavy duty vinyl adhesive with low water content should be used as on the actual wallcovering. This will prevent mildew.
- Any mildew must be removed from the walls and surfaces treated to inhibit further mildew growth.
- Acceptable hanging surfaces must be clean, smooth, thoroughly dry and structurally intact.
- Freshly plastered walls must be dry before application.
- Surface color should be uniform throughout the installation area. Variations in wall color may affect overall appearance of goods after installation.
- The temperature in the area of installation and/or storage should be maintained above 55° F at all times.
- Adequate lighting is necessary for a proper installation.

For additional information,
please contact Customer Service at
textiles_orders@knoll.com or 866.565.5858.
knolltextiles.com

Adhesive

- Hang wallcovering with a premium quality, heavy-duty, clear, pre-mixed adhesive.
- Use of any other type of adhesive will be solely at the risk of the installers.

Application

- Campagna Wall is a straight hang, pattern match product.
- Cut rolls in sequential order starting with the highest number and working down to the lowest number. Number panels and headers as they are cut from the roll and apply to the wall in the same sequence.
- Use only lead pencil for marking walls and back of wallcovering. Do not use ballpoint or marking pen, they will bleed through the surface.
- Markings on lighter color materials may telegraph through to the face. It is recommended that you use an alternate method to indicate "top", "bottom", and sequence numbers.
- If working with multiple lots, make certain that the lot numbers are separated at break points, such as corners. (DO NOT INTERMINGLE MULTIPLE LOTS)
- Cut each panel at the top of the dialogue box seam guide. This will aid with pattern alignment when hanging the drops.
- The wallcovering should be table trimmed. To aid in pattern matching at the seams, do not double cut.
- Use of a straight-edge and a razor is recommended. Blades must be changed after every cut.
- Trim edges .25" past the dialogue box seam guides to allow balanced spacing between each drop.
- Do not crease wallcovering.
- Use a wallcovering brush or a plastic scraper to smooth the wallcovering onto the wall. Metal scrapers may damage the surface.

General

- Ordinary dirt and smudges can be removed using a soft, lint-free cloth with mild soap and warm water.