

Dividends Horizon® Beltway Electrical Power Module

1. Remove Beltway Cover

© Knoll, Inc. 2020


- 2. Remove screws holding Beltway Skin Bracket (2A), Remove Beltway Skin Bracket (2B).
- 3. Attach the Beltway Skin Bracket to the Beltway Electrical Channel using (2) $\#10 \times 3/8$ " screws.
- A. Rotate the bracket/channel to fit inside the frame and align the screw holes on one side.
 - B. Reinsert one (1) of the previously removed screws
 - **C.** Rotate channels unil screw holes are aligned on the other side of the assembly.
 - D. Repeat step 4B.






Dividends Horizon® Beltway Electrical Power Module, continued

- 5. Insert Power Module by
 - A. Hooking plastic end and
 - **B.** swinging into position until tab locks securely.
- 6. Repeat Steps (5A) and (5B) for opposite side.
- 7. Engage the Duplexes into the Power Module and secure with the screw provided.
- 8. Repeat Step (7) for opposite side.
- **9.** Remove outer knock-out covers on the Beltway Cover.
- 10. Replace the Beltway Cover.



Note: View shown as cross-section for clarity

Knoll



DISASSEMBLY FOR RECYCLING

Materials Identification and Segregation:

Where possible plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non-marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.

Part Number: 7730C15H01