

Avio Sofa System

Avio Sofa System Elements

Base frame

Seats

Table tops (if applicable)

Hardware


M10x35 cap screws (base to base)

M8 sex bolt (seat/table to base)


M6x15 cap screws (base to top)

Base frames


End / intermediate tables



End / L-shaped tables




Seating elements





Tools needed

Allen wrench



End / L-shaped tables





End / intermediate tables




End / corner elements




Assymetric end elements





Intermediate elements



Intermediate / end ottoman





Assymetric end elements





Avio Sofa System



Configuration	Description	Components
AVC35	Two-seat sofa, righthand table	1 End element - left (A) 1 Intermediate element (B) 1 Square table (C)
AVC36 (not shown)	Two-seat sofa, lefthand table	



Configuration	Description	Components
AVC43	Three-seat sofa, righthand table	1 End element - left (A) 2 Intermediate element (B) 1 Square table (C)
AVC44 (not shown)	Three-seat sofa, lefthand table	





Configuration	Description	Components
AVC37	Two-seat sofa, righthand L-shaped table	1 End element - left (A) 1 Intermediate element (B) 1 L-shaped table - right (C)
AVC38 (not shown)	Two-seat sofa, lefthand L-shaped table	





Avio Sofa System Configurations



Configuration	Description	Components
AVC45	Three-seat sofa, righthand L-shaped table	1 End element - left (A) 2 Intermediate element (B) 1 L-shaped table - right (C)
AVC46 (not shown)	Three-seat sofa, lefthand L-shaped table	



Configuration	Description	Components
AVC88	Three-seat sofa, righthand asymmetric seat, lefthand table	1 Asymmetric end element - right (A) 2 Intermediate element (B) 1 Square table (C)
AVC89 (not shown)	Three-seat sofa, lefthand asymmetric seat, righthand table	




Configuration	Description	Components
AVC33	Three-seat sofa, righthand Ottoman return	1 End element - right (A) 1 End element - left (B) 1 Intermediate element (C) 1 Ottoman (D)
AVC34 (not shown)	Three-seat sofa, lefthand Ottoman return	



Knoll


Avio Sofa System

Configuration	Description	Components
AVC76	Three-seat sofa, righthand asymmetric seat, L-shaped table	1 Asymmetric end element (A) 2 Intermediate element (B) 1 L-shaped table - left (C)
AVC75 (not shown)	Three-seat sofa, lefthand asymmetric seat, L-shaped table	




Avio Sofa System Configurations


Configuration	Description	Components
AVC87	Five-seat sofa, asymmetric corner seat	1 Asymmetric corner element (A) 1 End element - left (B) 1 End element - right (C) 2 Intermediate element (D)



Configuration	Description	Components
AVC81	Four-seat sofa, righthand L-shaped table, asymmetric seat	1 Asymmetric corner element (A) 1 End element - left (B) 2 Intermediate element (C) 1 L-shaped table - right (D)
AVC82 (not shown)	Four-seat sofa, lefthand L-shaped table, asymmetric seat	





Configuration	Description	Components
AVC65	Five-seat sofa, righthand L-shaped end table	1 End element - left (A) 1 Corner element - right (B) 3 Intermediate element (C) 1 L-shaped table - right (D)
AVC66 (not shown)	Five-seat sofa, lefthand L-shaped end table	





Avio Sofa System

Configuration	Description	Components
AVC61	Five-seat sofa, righthand corner table	1 End element - left (A) 1 End element - right (B) 3 Intermediate element (C)
AVC62 (not shown)	Five-seat sofa, lefthand corner table	1 Corner table (D)





Avio Sofa System Configurations



Configuration	Description	Components
AVC91	Six-seat sofa, lefthand L-shaped table, asymmetric seat	1 Asymmetric end element (A) 1 Corner element - left (B) 4 Intermediate element
AVC90 (not shown)	Six-seat sofa, righthand L-shaped table, asymmetric seat	1 L-shaped table - left (D)



Configuration	Description	Components
AVC73	Five-seat sofa, righthand L-shaped end table and Ottoman	1 Corner element - right (A) 4 Intermediate element (B) 1 L-shaped table - right (C)
AVC74 (not shown)	Five-seat sofa, lefthand L-shaped end table and Ottoman	1 Ottoman (D)



Configuration	Description	Components
AVC1L	Single-seat sofa, lefthand Ottoman	1 Corner element - right (A) 1 Ottoman (B)
AVC1R (not shown)	Single-seat sofa, righthand Ottoman	



Avio Sofa System

Step 1.

Position the base frames on the floor.

Slide base frames (A) and (B) together.




Fig. 1

Step 2.

Attach the base frames together using 4 M10x35 cap screws; use Allen wrench.

Tighten the screws in the order 1 to 4, shown in Fig. 2.




Fig. 2

Avio Sofa System

Step 3.

Slide base frame assembly (A+B) and (C) together.




Fig. 3

Step 4.

Attach the base frames together using 4 M10x35 cap screws; use Allen wrench. Tighten the screws in the order 1 to 4, shown in Fig. 4.




Fig. 4





Fig. 5

Avio Sofa System

Step 5.

Position each seat (D) above the base frame (A+B+C).



Step 6.

Ensure that the threaded pins on the underside of each seat are positioned above the 4 attachment sleeves on the base frame assembly.




Fig. 7

Step 7.

Slide the 2 threaded pins (E) on the rear of each seat into the attachment sleeves.




Fig. 8

Avio Sofa System

Step 8.

Pivot the seat forward to slide the 2 threaded pins (F) on the front of each seat into the attachment sleeves.




Fig. 9

Step 9.

To attach each seat to the frame, screw the M8 sex bolts (G) on to the threaded pins; 4 bolts per seat. Use Allen wrench.




Fig. 7

Avio Sofa System

Step 10.

To attach end / intermediate table tops to the base frame assembly, position the threaded inserts on the underside of the top over the base frame screw holes (H).




Fig. 6

Step 10.

Attach each square top using M6x15 cap screws (I); square tops require 4 screws. Use Allen wrench.





Fig. 7

Avio Sofa System

Step 11.

To attach the end / L-shaped table tops to the base frame assembly, position the threaded inserts on the underside of the top over the base frame screw holes (J).



Step 11.

Attach the tops using M6x15 cap screws. The larger top (K) requires 10 screws, the longer top (L) requires 6 screws. Use Allen wrench.

