


EWC Sport™ Task Chair

Operating Instructions


Seat Height

To raise the seat height, remove your weight from the chair while lifting the lever under the right side of the seat. To lower the seat height, lift the lever while sitting in the chair.



Tilt Lock

To recline, pull out the lever under the right side of the seat. To lock the chair upright, push the lever in.



Tilt Tension

To adjust the tilt tension, turn the knob under the front of the seat. Turn counterclockwise to tighten, and clockwise to loosen.




Back Height

To raise the back height, firmly hold both sides of the back and lift. The back height adjusts 9 notches upward for a total of 2.5" of adjustability. To lower the back height, first raise the back to the highest position; the top notch releases the back to the lowest position.




Adjustable Arm Width

To adjust the arm width, loosen the knob under the arm support by turning clockwise. Slide the support toward or away from the seat to adjust the arm width. Tighten the knob under the arm. The arms adjust 1" in width per side (2" total).



Adjustable Arm Height (Optional)

To adjust the arm pad height, lift the lever on the outside of the arm support and move the arm up or down. Release the lever to lock. The arms have a 3.5" range of adjustment.



Sliding Seat Depth Adjustment (Optional)

To adjust the seat depth, lift the lever under the left side of the seat and slide the seat to the desired location. Release the lever to lock. There are 6 positions within a 2.75" range.

