Installation Instructions

CLAMP-ON OUTLET, OFFSET

202 Corded -

Instruction Number: 6TP00525, 2MA2996

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Tools Required .






NOTE


Remove Data Port Cover and Blank Adapters



2 Install Data Port Options (VGA, RJ45, HDMI, BLANK)
NOTE
See Sheet #2 for Detailed Instructions



Slide Bracket Behind Worksurface




Install Bottom Bracket Under the Worksurface

Option

* Underside of Worksurface *

HDMI

Option



E.C.N. No: GD17-002883

Part Number: G110233

Page Number: 1 of 3

Revision: B

Installation Instructions

CLAMP-ON OUTLET, OFFSET

Instruction Number: 6TP00525, 2MA2996

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.





(Specific)

Ortronics TrackJack


NOTE


All Tech Adapters Need to be Mounted in the ☆ "UP" ☆ Position. (Refer to the back of Parts)




Install Data Tech Adapter Option


Screw Driver or Wrench






(Universal)		
	KEYSTONE	
	HDMI	Optical Cable Corp 5e
	Tripp-Lite	Optical Cable Corp 6
	Allen-Tel	Ortronics
	AMP TE-Krone	Panduit NetKey
	Belden KeyConnect	Hubbell Premise
	Leviton Quick Port	Type F Coax
	Leviton Quick Port Extreme	ETC. (ET. AL.)






Panduit Mini-COM




(Specific)

Siemon




(Specific) Cable Retainer








Install Blank Tech Adapter Option





Commscope



E.C.N. No: GD17-002883

Part Number: G110233

Page Number: 2 of 3

Revision: B

This device complies with part 15A of the **CLAMP-ON OUTLET, OFFSET** FCC Rules. Operation is subject to the 202 following two conditions: (1) This device - Corded may not cause harmful interference, and Instruction Number: 6TP00525, 2MA2996 (2) this device must accept any interference Installation Instructions received, including interference that may cause undesired operation. Tools Required _ Screwdriver needed for optional #15 Torx power cord mounting clamps. Screw Driver or Wrench Secure Thumb Screws and Route Power Cord Option to Nearest Power Distribution Source (A) * Underside of Worksurface * #8 x 1/2" Pan Head Screw -Optional-Power Cord Mounting Clamps (A) Screws NEMA Plug **OFFSET** CLAMP-ON 202 Elevation Detail Worksurface Thickness Range * Side of Worksurface * (3/4" to 1-1/2")

E.C.N. No: GD17-002883 Part Number: G110233

Page Number: 3 of 3

Revision: B