



Knoll Systems  
Installation Instructions

## CLAMP-ON OUTLET


412

- Corded -

Instruction Number: 6TP00514, 2MA2965

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Tools Required



### \*NOTE\*

All Tech Adapters Need to be Mounted in the  
⬆ "UP" ⬆ Position. (Refer to the back of Parts)


### 1 Remove Data Port Cover and Blank Adapters




### 2 Install Data Port Options (VGA, RJ45, HDMI, BLANK)

#### \*NOTE\*

See Sheet #2 for Detailed Instructions




### 3 Slide Bracket Behind Worksurface



\* Top of Worksurface \*

### 4 Install Bottom Bracket Under the Worksurface

\* Underside of Worksurface \*





Knoll Systems  
Installation Instructions

## CLAMP-ON OUTLET

412

- Coded -

Instruction Number: 6TP00514, 2MA2965

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Tools Required




### \*NOTE\*

All Tech Adapters Need to be Mounted in the  
↑ "UP" ↑ Position. (Refer to the back of Parts)

## 2.1

### Install Data Tech Adapter Option



(Universal)

#### KEYSTONE

HDMI	Optical Cable Corp 5e
Tripp-Lite	Optical Cable Corp 6
Allen-Tel	Ortronics
AMP TE-Krone	Panduit NetKey
Belden KeyConnect	Hubbell Premise
Leviton Quick Port	Type F Coax
Leviton Quick Port Extreme	ETC. (ET. AL.)

(Specific)

Belden EZ MDVO

(Specific)

Panduit Mini-COM

(Specific)


Siemon

(Specific)


Cable Retainer

## 2.2

### A Install VGA Connector to VGA Tech Adapters




### B Install VGA Adapter Assembly into Unit



## 2.3

### Install Blank Tech Adapter Option





Knoll Systems  
Installation Instructions

## CLAMP-ON OUTLET

412

- Corded -

Instruction Number: 6TP00514, 2MA2965


This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Tools Required



#15 Torx

Screw Driver or Wrench



Screwdriver needed for optional  
power cord mounting clamps.


**5**

### Secure Thumb Screws and Route Power Cord Option to Nearest Power Distribution Source


(A)



#8 x 1/2" Pan Head Screw



\* Underside of Worksurface \*



-Optional-  
Power Cord  
Mounting Clamps  
(A) Screws

OVER CURRENT  
PROTECTION  
PLUG

Elevation  
Detail

CLAMP-ON  
OUTLET 412

\* Side of Worksurface \*

Worksurface  
Thickness Range  
(3/4" to 1-1/2")