

Antenna® Tech-back Low Hybrid Storage

Pattern Numbers Represented:

YNFTOS28__

YNFTBP28__


Parts List:



Spring Clip (A)
3AJ4147

Tools needed:

None



Steps:

1. Tilt back panel so that lower clip engages rectangular flange slot on back of low storage (Fig. 1a, 1b).





Fig. 1a





Fig. 1b



DISASSEMBLY FOR RECYCLING

Materials Identification and Segregation:

Where possible plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non-marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.

Antenna® Workspaces Hybrid Tech-back Low Storage, continued

Steps continued:

- 2. Tilt back panel vertical and clip top with two spring clips (A).

