
Dividends Horizon® High-Low and Alternative Panel and Post Configurations (Full View and Topway)

High-Low Panel to Panel




Dividends Horizon® High-Low and Alternative Panel and Post Configurations (Full View and Topway), continued

High-Low Panel to Panel


Notes: Post connections shown for two way connections (repeat same steps for straight, three way and four way)


More comprehensive details are shown on Installation Instructions for Same Height Assembly (2MA2452)


- 1. Assemble hardware (Fig. 1)
- 2. Assemble hardware onto frame (Fig. 2)
- 3. Bring panels together (Fig. 3)
- 4. Lift tallest panel, bring panels completely together. Allow lifted panel to lower back down until all hardware and panels are fully engaged.
- 5. Tighten 7" screw












Dividends Horizon® High-Low and Alternative Panel and Post Configurations (Full View and Topway), continued


High-Low Panel to Post


- 1. Assemble hardware (Fig. 1)
- 2. Assemble hardware onto frame (Fig. 2)
- 3. Bring post to panel (Fig. 2)
- 4. Lift post, bring completely together with panel, allow post to lower back down until




Dividends Horizon® High-Low and Alternative Panel and Post Configurations (Full View and Topway), continued

Alternative Panel Configurations







DISASSEMBLY FOR RECYCLING

Materials Identification and Segregation:

Where possible plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non-marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.