

Stromborg Rectangular Tables w/ Stone, Marble or Laminate Tops


Pattern numbers represented:

DS14-(O118, GCO, VB)

DS16-(O118, GCO, VB)




G. #10 Phillips truss head screw




H. 5/16-18 Hex drive soc cap screw

Parts List:

- A. 1x Table top
- B. 4x Leg Assembly
- C. 2x Long cross rail
- D. 2x Short cross rail
- E. 4x Y-casting
- F. 4x Outdoor glide
- G. 4x #10 Philips truss head screw
- H. 24x 5/16-18 Hex drive soc cap screw
- I. 8x 1/4-20 Hex drive soc cap screw
- J. 1x Center stand-off
- K. 4x 1/4-20 Phillips truss head screw
- L. 4x Plastic spacer
- M. 4x Rubber washer
- N. 4x 1/4" Washer
- O. 4x Indoor glide



I. 1/4-20 Hex drive soc cap screw




K. 1/4-20 Phillips truss head screw

Tools Required:

- Philips driver #2 tip
- Allen wrench 3/16" & 1/4"

Exploded View



DISASSEMBLY FOR RECYCLING

Materials Identification and Segregation:

Where possible plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non-marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.

Stromborg Rectangular Tables w/ Stone, Marble or Laminate Tops, continued

STEPS

1. Leg/Cross rail assemblies (B) will arrive with outdoor glides (F) installed as seen in Fig 1.

2. For indoor table use, remove #10 Phillips truss head screws (G) and outdoor glides (F), and replace with indoor glides (O). See Fig 2.

Fig 1






Fig 2




Stromborg Rectangular Tables w/ Stone, Marble or Laminate Tops, continued

STEPS

3. Attach long cross rails (C) and short cross rails (D) to Y-castings (E) using screws (H) and 1/4" allen wrench.



H. 5/16-18 Hex drive soc cap screw



I. 1/4-20 Hex drive soc cap screw

4. Next, attach leg assemblies (B) to Y-castings (E) using screws (H) and 1/4" allen wrench.

Note: Do not tighten screws. Keep screws loose for final adjustment.

Fig 3





Fig 4

5. Attach the center stand-offs (J) to long and short cross rails with screws (I) using 3/16" allen wrench. See Fig 4.


Note: Make sure screws are flush to bottom surface of cross rails.



Stromborg Rectangular Tables w/ Stone, Marble or Laminate Tops, continued

STEPS

6. Place spacers (L) between leg assembly (B) and table top as seen in Fig 5.



K. 1/4-20 Phillips truss head screw

7. Attach leg assembly to top using washers (M), washers (N), and screws (K). See Fig 5. Tighten screws to 40 in/lbs torque.

8. Align table top corner to top of leg as seen in Fig 6. Tighten screws (H) on Y casting to 80 in/lbs torque.

Note: Ensure screws are fully seated. The top of screw head should be ~ 3/16" below bottom of cross rail. Failure to fully seat screws could result in unstable table.

9. Adjust center stand-offs (J) to make contact with bottom side of table top surface. See Fig 7.

Fig 5




Fig 6




Fig 7

